

# autoPilot Concept


for PVCu windows



for  
windows




# Adjustment instructions




### Corner hinge

Height adjustment ( $\pm 3 \text{ mm}$ ) and side adjustment ( $\pm 2 \text{ mm}$ ) of the corner hinge.




### Eccentric cam

Regulation of the installation pressure between the sash and the frame ( $\pm 0,8 \text{ mm}$ ) by pulling up and adjusting the eccentric cam.



### Shear retraction

In middle position: 18 mm. Progresses the shear retraction: 28 mm. Alternatively, a MSL OR SL variable to device can be inserted (see Top rods / shears).



### Shear

Adjustment of the closing pressure ( $\pm 0,8 \text{ mm}$ ) and the lifting and the lowering of the sash (from - 2 to + 3,5 mm).

General product information

0

Fitting overviews

1

Drive rods

2

Corner drives

3

Top rods, shears and shear hinges

4

Interlocking rods

5

Shear and corner hinges

6

Accessories

7

Fitting variations

8

Turn only fittings

9

Frame Parts

10

Mounting accessories

11

Mounting instructions

**Winkhaus Fenstertechnik GmbH & Co. KG**

August-Winkhaus-Straße 31  
D-48291 Telgte  
T +49 (0) 25 04-921-0  
F +49 (0) 25 04-921-340

[www.winkhaus.de](http://www.winkhaus.de)  
[fenstertechnik@winkhaus.de](mailto:fenstertechnik@winkhaus.de)